



For assistance, contact our help desk or find answers online at:

[www.labtechttests.com](http://www.labtechttests.com)

## Hydrogen Sulfide Test

Since hydrogen sulfide can be detected in water by “rotten egg” smell and taste, test strips are usually not needed to detect its presence.

**1**

Turn on the cold water; let it run for 1 minute and smell. Turn off the cold water.

Turn on the hot water. Let it run for 1 minute and smell the water.



**2**

If the rotten egg smell is present in both, hydrogen sulfide is present in your water supply. If you detect it in the hot water only, the smell is from a reaction in your hot water heater.

**WARNING!** This set contains chemicals that may be harmful if misused. Read cautions on individual containers carefully. Not to be used by children except under adult supervision.



Backed by over  
80 years experience

LabTech® W6585 Highway O • Millston, Wisconsin 54643 [www.labtechttests.com](http://www.labtechttests.com)